



09/14/19





NOTE:
IF ENGINE IS RUNNING, DOCK LT SW
RECEIVES POWER FROM THE BACK-UP
LIGHTS RELAY AND WILL ONLY WORK IN
REVERSE AS ADDITIONAL BACK-UP LTS.
WITH ENGINE OFF, POWER IS SUPPLIED
BY CHASSIS BATTERY AND THE LIGHTS
WILL WORK ANYTIME THE SWITCH IS ON.
THE SWITCH PILOT LIGHT IS ON
WHENEVER THE DOCKING LIGHTS ARE ON.