



WINNEBAGO DWG: 157300 (UNO)

THE AUX START SOL IS USED TO COMBINE THE CHASSIS & COACH BATTERIES FOR EXTRA STARTING CURRENT USING THE DUAL BATT SW MOMENTARY.

ANY TIME THE ENGINE IS RUNNING, A GND SIG FROM THE LIGHT BAR WILL ACTIVATE THE AUX START RLY WHICH WILL FIRE THE AUX START SOL VIA THE DUAL BATT SW. THIS WILL COMBINE THE BATTERY BANKS FOR CHARGING FROM THE ALTERNATOR.

Project: 07 WINNEBAGO JOURNEY		DATE	12/7/15
Owner: James Exler		FIRST RELEASE	7/1/17
Address: 823 W River Stone Ct		ADD AUX START NOTES	
City, St, Zip: Nampa, ID 83686			
Parcel Number: (208) 461-7033			
Title: RUN ONLY POWER DIST			
Job Number		34H	
Drawn Date		12/7/15	
Drawing Scale		N/A	
Drawn By	JIM X	Rev #	1
Drawing Number		RUN PWR	

This document and the design it covers are the property of JAMES EXLER. They are loaned only with the borrower's expressed agreement that they will not be reproduced, copied, loaned, exhibited, or used in any other way, except by written consent from JAMES EXLER.

REV	0	BY	JE	DESCRIPTION
REV	1	BY	JE	ADD AUX START NOTES

RunOnlyPwr.dwg